



- 03. 환수막대 (PLACARD BATTEN)
- 05. 발무대 조명 1 (#1 APRON LIGHT)
- 01. 반사음확산시트 (ACOUSTICAL SHELL - POOSCENIUM CEILING)
- 00. 영점선 (ZERO LINE)
- 01. 안전막 (SAFETY CURTAIN)
- 02. 안막 (HOUSE CURTAIN)
- 03. 오양막 (CONTOUR CURTAIN)
- 04. 양막 1 (#1 SET BATTEN)
- 05. 프로시니엄브리지 + 후막막 (PROSCENIUM BRIDGE + HOUSE BORDER)
- 06. 양막사기 (HAND TORMENTOR)
- 07. 양막 2 (#2 SET BATTEN)
- 08. 양막 3 (#3 SET BATTEN + DRAW CURTAIN)
- 10-13. 양막 4 - 7 (#4 - #7 SET BATTEN)
- 14. 양막막 (SCREEN)
- 15-18. 양막 8 - 11 (#8 - #11 SET BATTEN)
- 19. 양막 12 + 양막 (#12 SET BATTEN + DRAW CURTAIN)
- 20-28. 양막 13 - 22 (#13 - #22 SET BATTEN)
- 30. 양막 23 + 양막 (#23 SET BATTEN + DRAW CURTAIN)
- 31-41. 양막 24 - 34 (#24 - #34 SET BATTEN)
- 42. 양막 35 + 양막 (#35 SET BATTEN + DRAW CURTAIN)
- 43-54. 양막 36 - 47 (#36 - #47 SET BATTEN)
- 55. 양막 48 + 양막 (#48 SET BATTEN + DRAW CURTAIN)
- 56-60. 양막 49 - 53 (#49 - #53 SET BATTEN)
- 61. 후막막 (REAR SCREEN)
- 62. 후막막 조명 + 후막막 (REAR CYC. LIGHT + HOUSE BORDER)
- 63. 양막 54 (#54 SET BATTEN)
- 64. 양막 55 (#55 SET BATTEN)
- 65. 흑막 (BLACK CYCLODRAM)
- 66. 하막막 (CYCLODRAM)

- 67. 발무대 조명 1 (#1 REAR STAGE LIGHT BATTEN)
- 68. 발무대 조명 2 (#2 REAR STAGE LIGHT BATTEN)
- 69. 발무대 조명 3 (#3 REAR STAGE LIGHT BATTEN)